

# PoE 8 Channel H.265 8MP NVR with 1HDD Bay and Facial Recognition

---

WNVR18P5AI



Quick Start Guide

Please read these instructions carefully before operating the unit  
and keep for further reference.

genie

Please read this instruction carefully before operating the product and keep it for further reference. All examples and pictures used here are for reference only. The contents of this manual are subject to change without notice.

**CAUTION:**

- Please check the device and the accessories after getting the device. If there are any damages, shortages or defects, please contact your dealer immediately.

1.0 Introduction.....	4
1.1 Product Features.....	4
1.2 Product Dimensions .....	4
1.3 Specification.....	5
2.0 HDD Installation .....	6
3.0 Rear Panel Instruction.....	7
4.0 Start Up and Shut Down.....	8
5.0 Login .....	9
6.0 Configurations and Connections .....	10
6.1 Network Configuration & Adding IP Camera.....	10
7.0 UPnP .....	12
8.0 NAT.....	13
9.0 Manual Recording and Playback .....	14
9.1 Manual Recording.....	14
9.2 Playback.....	14


## 1.0 Introduction

The Genie WNVR18P5AI is an 8 channel PoE H.265 8MP NVR with 1 HDD bay and facial recognition. The NVR supports 8 channel 8MP, 6MP, 5MP, 4MP, 3MP, 1080p, 1280 × 1024, 960p, 720p, 960H, D1 and CIF IP video input as well as 8 channel simultaneous playback.

### 1.1 Product Features

- Supports 8 CH 8MP, 6MP, 5MP, 4MP, 3MP, 1080p, 1280×1024, 960p, 720p, 960H, D1, CIF IP video input
- Standard H.265 high profile compression format to get high-quality video at much lower bit rate
- Intuitive and user-friendly Graphic User Interface (GUI), Windows style operation by mouse
- Multi-mode recording: Manual / Timer / Motion / Sensor / Smart events
- Playback : 8CH simultaneous playback
- Supports face detection and comparison
- Search : Time slice, time, event, tag, smart and face database search
- Multi-user online simultaneously
- Authorisation management, log view and device status view
- Supports multiple VCA (Video Content Analytics) events, such as object abandoned/missing, region intrusion, tripwire, video tampering, etc.
- Supports POS information overlay on live view and playback
- Express and flexible backup via USB, network and so on.
- Pentaplex : Preview, record, playback, backup and remote access
- DHCP, DDNS, PPPoE network protocol
- Remote control via Web Client or CMS : Preview, playback, backup, PTZ and configuration
- 8 PoE network ports, PoE power supply supported
- Dual stream technology for local storage with high definition, remote network transmission and remote surveillance with mobile device
- 4K output, true high resolution display
- Supports PTZ preset and auto cruise, up to 255 presets and 8 cruises
- Supports NAT function and QR code scanning by mobile phones
- Powerful mobile surveillance by smart phones with iOS and Android OS
- P2P ready for hassle free remote access

### 1.2 Product Dimensions



## 1.3 Specification


Model		WNVR18P5AI
System	OS	Embedded Linux
Video	Input	8CH IPC input
	Incoming Bandwidth	80Mbps
	Output	HDMI x 1 : 3840×2160 @60fps / 3840×2160 @ 30fps / 1920×1080 / 1280×1024 / 1024×768 VGA 1 : 1920×1080 / 1280×1024 / 1024×768
	Resolution	8MP / 6MP / 5MP / 4MP / 3MP / 1080p / 1280×1024 / 960p / 720p / 960H / D1 / CIF
	Compression	Standard H.265/H.264
Audio	Input	8 CH IPC audio input
	Output	RCA x1
	Two-Way Audio	RCA x1
	Compression	G.711 (A/U)
Record	Record Stream	Dual stream recording
	Resolution	8MP / 6MP / 5MP / 4MP / 3MP / 1080p / 1280×1024 / 960p / 720p / 960H / D1 / CIF
	Frame Rate	NTSC: 30fps, PAL: 25fps
	Mode	Manual, Timer, Motion, Sensor, Smart events
Face Recognition	Channel	8CH
	Face Picture Database	32 libraries, 5000 face pictures
	Computing Capability	180 pictures / minute
	Face Picture Search	Search by picture is supported
	Database Management	Add, modify, delete and search face pictures
	Face Picture Adding	Add face pictures through App, Web and external import
	External Face Picture Enrolment	Resolution: 128×128, 1920×1080, Size: ≤ 70KB, Format: jpg&jpeg
	Face Picture Comparison	Supports allow list and block list alarm
	Face Track	Yes
	Map of Face Track	Resolution: 2560×1920, Size: ≤ 512KB, Format: jpg&jpeg
	Statistic Graph of Face Information	Bar graph
Statistic Mode of Face Information	Statistics by day, week, month, quarter as well as customised time period	
Mobile Device	OS	iOS, Android
Storage	HDD	SATA x1, max 8TB per HDD
Playback	Playback	Maximum 8CH (Simultaneous)
	Search	Time slice / Time / Event / Tag search
	Smart Search	Highlighted colour to display the camera record in a certain period of time, different colours refers to different record events.
	Function	Play, Pause, FF, FB, Digital zoom, etc.
Alarm	Mode	Manual, Sensor, Motion, Exception, Smart events
	Input	8 CH local alarm input, supports IPC alarm input
	Output	4 CH
	Triggering	Record, Snap, Preset, E-mail, etc.
Network	Interface	RJ45 1000Mbps x 1
	Protocol	TCP / IP, PPPoE, DHCP, DNS, DDNS, UPnP, NTP, SMTP
	PoE Port	RJ45 × 8 (IEEE802.3af, output power: ≤80W)
Remote Monitoring	Immix	Compatible with Immix via RTSP only (2-way audio not supported)
	Sentinel	Yes, Firmware 1.1.0 or later
Backup & Storage	Local Backup	USB stick, USB mobile HDD
	Network Backup	Yes
	Storage	HDD: SATA x1, max 8TB per HDD
Port	RS485	Yes (Full-duplex), Connect to PTZ or keyboard
	USB	USB 2.0 × 1, USB 3.0 × 1
	Remote Controller	Optional
Others	Power Supply	DC48V/2.5A
	Consumption	≤ 15W (Without HDD and PoE power supply)
	Working Environment	-10~50°C, 10%~90% (Humidity)
	Dimensions	300 × 249 × 45 mm

## 2.0 HDD Installation

---

This series of the product supports 1 SATA hard drive. Please make sure that the device is powered off before the installation. The pictures of the installation are for reference only.

1. Loosen the screws to open the cover.
2. Screw the screws into the HDD but do not tighten them.
3. Place the HDD onto the bottom of the machine.
4. Turn over the machine and secure the HDD with the screws.
5. Connect the power and data cables.




6. Install back the cover and secure it with the screws.

*Note: Please check the inside structure of the device and make sure that the cables are connected well before installing the cover back. Please format the HDD before using.*

### 3.0 Rear Panel Instruction

The interfaces of the rear panel are for reference only.



Name	Description
DC48V	Connector for power input
PoE Ports	PoE network ports, connect to PoE IP camera
LAN	Network port
VGA	Connect to monitor
HDMI	Connect to high definition display device
USB	Connect to USB storage device or USB mouse
AUDIO OUT	Audio output
AUDIO IN	Audio input
P/Z	P/Z; Connector for PTZ
K/B	K/B; Connector for keyboard
ALARM IN	Alarm input, connectors for sensors
ALARM OUT	Alarm inutput
GND	Ground

## 4.0 Start Up and Shut Down

---

### Startup

1. Connect the monitor and the power.
2. The device will boot and the power indicator will display blue.
3. A wizard window will pop up.


### Shutdown

Click "Start" and then select "Shutdown" icon. This will bring up a shutdown window. The device will shut down by clicking "OK" button. Then disconnect the power.



## 5.0 Login

---



Username: admin

Password: Enter Password

Display Password  Log In Automatically

Edit Security Question Login Cancel


The default username is admin and the default password is 123456. You must configure the wizard if you start the NVR for the first time and you may change the password when you configure the wizard for the first time. You can skip the settings wizard next time. Click "Start" and select "Login". This will take you to see a login box. Enter the default username and password you set. Then you will see the live image.


## 6.1 Network Configuration & Adding IP Camera



After you finish adding IP cameras, you can see the live images through the monitor of the NVR. The following will mainly introduce how to add the IP cameras via LAN/WAN.


### LAN


1. Set the network of the NVR. Go to Start → Settings → Network → TCP/IP. Enter IP address, subnet mask, gateway, etc. If using DHCP, please enable DHCP in both the NVR and the router.
2. Go to Start → Settings → Network → Port. Enter HTTP port (the default value is 80), server port (the default port is 6036).
3. The internal ethernet port is the port which connects all the PoE ports with the NVR system. The PoE ports are available if the internal ethernet port is online. If it is offline, all the PoE ports will be unavailable. The IP address and subnet mask of the internal ethernet port can be changed to make the port in the same network segment with the IP cameras which directly connect to the PoE ports of the NVR.



4. Go to Start → Settings → Camera → Add Camera. The NVR will automatically refresh the cameras searched. The IPC which supports the Onvif protocol may be added manually. If the IPC searched is not in the same local network as the NVR, you should select the device and click  to modify the IP address.




5. Checkmark the device you want to add and then click "Add" button. The NVR will automatically refresh the cameras and return to "Edit Camera" interface. "Online" status means connecting the device successfully and you will see the live image. You may select the added device and click  button to modify channel, IP address, etc.



The screenshot shows the 'Camera Signal' and 'IP Planning' tabs. A search bar is at the top right. Below is a table with columns: No., Camera Name, Address, Port, Status, Protocol, Model, Preview, Edit, Upgrade, and Version.

No.	Camera Name	Address	Port	Status	Protocol	Model	Preview	Edit	Upgrade	Version
1	IP Camera 1	192.168.1.45	80	Online	XXX	XXX				4.1.0.0
2	[A01]Camera1									
3	[A02]Camera2									
4	[A03]Camera3									
5	[A04]Camera4									




The 'Edit Camera' dialog box contains the following fields:

- Camera Name: IP Camera 1
- Address: 192.168.1.58
- Port: 80
- Protocol: XXX
- Model: XXX
- Username: admin
- Password: [masked]


There is a 'Sync to IPC' checkbox and 'Test', 'OK', and 'Cancel' buttons at the bottom.


### WAN





1. Set the network of the NVR. Go to Start → Settings → Network → PPPoE. Enter static IP address or enable PPPoE and then enter the user name and password received from your ISP.
2. Go to Start → Settings → Camera. Click "Add Camera" or  behind the column of the search camera and select "Manually Add" to add the IP cameras. Enter IP address, server port, username and password of the IP camera. The IP camera must be connected over WAN. And here the IP address of the IP camera must be a WAN IP address.

## 7.0 UPnP

You can use the UPnP function to enable the fast connection of the device to WAN via a router without port mapping.


1. Go to Start → Settings → Network → UPnP, and enable UPnP and then click "Apply" button to save.
2. Enable the UPnP function in the router.
3. Click "Refresh" button to refresh the UPnP status. If the UPnP status were still "Invalid UPnP" after refreshing it for several times, the port would be wrong. Please change the mapping type to "Manual" and then click  to modify the port until the UPnP status turns to "valid UPnP".



Port Type	External Port	External Address	Port	UPnP Status	Edit
HTTP Port	80	183.17.254.19	80	Valid UPnP	
HTTPS Port	443	183.17.254.19	443	Valid UPnP	
Server Port	6036	183.17.254.19	6036	Valid UPnP	
RTSP Port	554	183.17.254.19	554	Invalid UPnP	


**NAT Settings**

1. The NVR shall be powered on and connected to the network.
2. Go to Start → Settings → Network → TCP/IP. You can obtain the IP address, subnet mask and gateway automatically. You can also manually enter them according to the actual network situation. Please make sure the network segment is the same as that of the network which is used.
3. Set the preferred or alternative DNS Server. Click "Apply" to save the parameters.
4. Go to Start → Settings → Network → NAT tab. Enable NAT and select the NAT Server Address (The default NAT Server Address is nat.autonat.com). Click "Apply" to save the parameters.




**NAT Access**

After finishing the NAT settings, you can enter [www.autonat.com](http://www.autonat.com) in the address bar of your browser and then press enter to go to the following interface. If you are the first time to access the NAT, you shall download and install the plug-in according to the tips. After installing the plug-in successfully, it will pop up the login box.



Device Serial Number:

Click  on the menu bar at the bottom of the live interface to check the serial number or go to Start → Settings → Network → Network Status to check the serial number of the NVR).



Username:

The username of the NVR. The default username is admin.

Password:

The password of the NVR. The password is set by yourself when you configure the wizard for the first time.

### 9.1 Manual Recording

Before recording, please install and format a HDD. In the live interface you can see the menu toolbar. Click  button to start recording. Click it again to stop recording. You can also click  to check the status of the recording.





### 9.2 Playback

#### Instant Playback

Click "Instant Playback" in the right-click menu of the camera's preview window to select or drag the playback progress bar to change the playback time to play back the record.

#### General Playback

Click  on the tool bar at the bottom of the live preview interface or click Start → Playback to go to the playback interface as shown below. You can also add the playback cameras manually. Click  in the playback window to pop up the "Add Camera" window. Check the cameras in the window and then click "Add" to add playback camera. The record files of the added playback camera will be played in the playback interface.



**Sales** +44(0)1707 330541

**Enquiries** [sales@genieproducts.co.uk](mailto:sales@genieproducts.co.uk)

**Website** [www.genieproducts.co.uk](http://www.genieproducts.co.uk)

**genie**