

# 1080p AHD IR Bullet Camera with 2.8–12mm Lens

---

WAHD2LBV



User Manual

Please read these instructions carefully before operating the unit  
and keep for further reference.

genie

Please read this instruction carefully before operating the product and keep it for further reference. All examples and pictures used here are for reference only. The contents of this manual are subject to change without notice.

### **CAUTION:**

- If the product does not work properly, please contact your dealer or the nearest service centre. Never attempt to disassemble the camera yourself. We shall not be responsible for any problems caused by unauthorised repair or maintenance.
- Do not allow water or liquid into the camera while in use.
- When using the product, you must be in strict compliance with the electrical safety regulations of the nation and region.
- When the product is mounted on wall or ceiling, the device needs to be firmly fixed.
- Make sure the power supply voltage is correct before using the camera.
- Do not drop the camera or subject it to any physical shock.
- If cleaning, please use a clean soft cloth with a little neutral detergent to wipe it gently.
- Do not aim the camera at the sun or in any area where there is bright lighting.
- The device may be burned out by a laser beam, so when any laser equipment is in use, make sure that the surface of the device will not be exposed to the laser beam.
- Do not place the camera in extremely hot, cold, dusty or damp locations, and do not expose it to high electromagnetic radiation.
- To avoid heat accumulation, good ventilation is required for operating environment.

# Contents

---

1.0 Introduction.....	4
1.1 Product Features.....	4
1.2 Product Dimensions .....	4
1.3 Specification.....	5
1.4 Functions .....	6
2.0 Cables .....	7
3.0 Product Installation.....	8
4.0 Call Up Main Menu .....	9


## 1.0 Introduction

The Genie WAHD2LBV is a 1080p AHD bullet camera with an integrated IR 2.8-12mm lens.

### 1.1 Product Features

- 1080p real-time image
- Analogue high definition (AHD) video output
- True Day / Night
- 30 ~ 50m IR Range
- IP66 ingress protection
- NDAA compliant

### 1.2 Product Dimensions



### 1.3 Specification

Camera	Image Sensor	1/3" CMOS
	Image Size	1080p (1920 × 1080)
	Image System	PAL / NTSC
	Resolution	1920 × 1080
	Electronic Shutter	1/50s ~ 1/50000s (PAL), 1/60s ~ 1/50000s (NTSC)
	Minimum Illumination	0 Lux (LED On)
	Lens	2.8–12 mm
	S / N Ratio	>52dB (AGC Off)
	Frame Rate	30 fps (60 Hz), 25 fps (50 Hz)
	Video Output	BNC x1
Functions	IR Distance	30 ~ 50 m
	Function Control	OSD
	Day & Night	Yes (ICR)
	WDR	Yes
	3D NR	Yes
	AGC	Yes
	White Balance	ATW, AWC, SET, Indoor, Outdoor, Manual
	Advanced Image	Sharpness, Saturation, Brightness etc are Adjustable
	Defog	Yes
	Smart IR	Yes
	Mirror	Yes
	Privacy Mask	Up to 8 Areas
	Motion Detection	Up to 4 Areas
	Defect Correction	Yes (Support Live and Static Defective Pixel Correction)
	Language	12 languages supported
Others	BLC & HLC	Yes
	Ingress Protection	IP66
	Power Supply	DC12V (±10°C)
	Working Environment	Temperature: -20°C ~ 50°C, Humidity: 10% ~ 90%
	Dimensions	109 × 284 mm
	Weight	1010g

## 1.4 Functions

### High Resolution

Adopt high performance sensor, providing high definition and clear image.

### High Transmission Performance

Real-time transmission with high speed and long distance.

### DNR

Reduce noise from brightness and colour signal.

### OSD

It's easy for the user to call the setup menu and configure the menu. The camera settings can be clearly displayed through the main menu.

### White Balance

Adjust the colour temperature according to the environment automatically.

### ICR Auto Switch

The filter will filter infrared light during the daytime and change to normal at night to ensure a high sensitivity and clear image.

### AGC

Adjust the gain of amplifier, enabling the camera to output the standard video signal in different lighting condition.

### Wide Dynamic Range (WDR)

When there are both very bright and very dark areas simultaneously in the field of view, this function will balance the brightness level and provide clear images.

### Backlight Compensation (BLC)

When the back of the captured object is too much bright, you can set BLC for the captured object to make it clearer.

### High Light Compensation (HLC)

Mask and compensation the high light area.

### Privacy Masking

This function allows you to block or mask certain area of a scene for privacy purpose.

### Motion Detection

The alarm will be triggered when there are moving objects captured by the camera.

## 2.0 Cables

The cables are only for reference. The default video output will be different for different cameras.

For the camera with video switch cable, there are two kinds of video switches, button switch and dial switch.


**Button Switch:** The video outputs will recycle by holding and pressing the button in the video switch cable for 5 seconds.

**Dial Switch:** Please set the video output according to the directions described on the tag of the video switch cable.

**Note:**

*Before switching video outputs, remove the cover of the video switch cable first.*


*\* Some models do not have the video switch cable, please go to OSD to change video outputs.*




### 3.0 Product Installation

Before you start, please make sure that the wall or ceiling is strong enough to withstand 3x the weight of the camera. Please install the camera in the dry environment.


1. Attach the drill template to the place where you want to fix the camera and then drill screw holes according to the drill template.
2. Route and connect the cables.
3. Secure the mounting base with the camera to the wall with screws as shown below.



4. Bracket adjustment. Before adjustment, preview the image of the camera on a monitor and then loosen the fixed ring or screws to adjust the view angle of the camera.




5. Focus and zoom adjustment (If the model you get is fixed lens or motorised lens, please skip this step). Remove the cover and then adjust the focus and zoom levers to get a clear image. Finally, tighten the screws and the lens cover.







## 4.0 Call Up Main Menu

### Access Main Menu

1. Press Enter  key of the rear panel or cable of the camera to go to the main menu.
2. Select the preview window and right click the mouse to show the following menu list on the DVR.









3. Click  on the toolbar at the bottom of the live preview window (or right click the mouse to select "PTZ Control").



4. Select the "OSD" tab and then click  /  to call up the main menu.

### Menu Operation

You can select the menu by clicking  (U) or  (D) key on the direction area. Click  (L) or  (R) key to select the menu on the left. The menu with arrow icon which means it has sub-menu. Click  /  to go to the sub-menu or confirm the settings.

If there are direction keys and enter key on the cables of the camera, you can also use these direction keys to select menu and the enter key to go to the sub-menu or confirm the settings.

#### *Note:*

*This series of the camera must be connected to the DVR which supports calling up main menu of camera. Different DVRs manufactured by different DVR manufacturers may have different modes of menu operation. Please refer to the relevant User Manual of DVR.*

*\* Some models may not support calling up main menu, please take the final product as the standard.*

**Sales** +44(0)1707 330541

**Enquiries** [sales@genieproducts.co.uk](mailto:sales@genieproducts.co.uk)

**Website** [www.genieproducts.co.uk](http://www.genieproducts.co.uk)

**genie**